



\*

Model	Thread Size
LSTS	M16 x 1
LSTL	M20 x 1

Laser Specifications:  
Class 2 laser product  
Output < 1 mW  
Wavelength 650 nm

#### Using the Laser Sighting Tool

1. Screw LST onto front of sensor
2. Push button 'A' to turn on laser

**WARNING: Do not aim laser directly or indirectly (via reflections) into eyes!**

3. Align sensor and lock in place
4. Push button 'A' to turn off laser
5. Unscrew LST from front of sensor

#### To Change Battery

1. Unscrew two halves of LST
2. Remove battery
3. Replace battery with Lithium 1/2 AA 3.6 V battery
4. Reassemble LST

Please note: The battery must be capable of providing a discharge current of at least 40 mA.

**CALEX**  
ELECTRONICS LIMITED

MATERIAL ALUMINIUM  
FINISH BLACK ANODISED

Laser Sighting Tool (LST)

All dimensions in mm